

Xsens DOT

iOS App Changelogs

Author: Product Manager
Last updated: September 22, 2020
Document: XD0205P



Symbol	Meaning
+	Added
^	Changed
!	Note
#	Fixed
-	Removed

Version 2020.2.2

Release date: September 29, 2020

Release type: Stable

Compatible firmware versions: 1.0.0, 1.4.0

Fixed the bug that there is no recording data when synchronization is disabled.

Version 2020.2.1

Release date: September 22, 2020

Release type: Stable

Compatible firmware versions: 1.0.0, 1.4.0

+ Add support to disable/enable synchronization before measurement.

Version 2020.2

Release date: August 27, 2020

Release type: Stable

Compatible firmware versions: 1.0.0, 1.4.0

- + Support power saving time adjustment.
- + Added heading reset function.
- + Added identify LED pattern after rename the sensor.
- + Support all the payload modes in real-time streaming.
- + Added crash information collection.
- + Support recording function.
- + Added reminder to back up the recording data before OTA.
- + Support synchronization function in real-time streaming and recording.
- + Display serial number in Settings.
- ^ Improved the axis scale flexibility in plotting charts.
- ^ Improved some text in app.
- ^ Change "dQ", "dV" to "dq", "dv" in logging csv.

Xsens DOT

iOS App Changelogs

Author: Product Manager
Last updated: September 22, 2020
Document: XD0205P



- Removed the reconnection attempt after sensor is powered off by button during connection.
- Remove support for special characters in tag name.
- # Fixed the wrong packet counter in logging csv after sensor reset.
- # Cannot open CSV file with correct separator has been fixed.
- # Logging csv files of the same real-time streaming measurement are stored in 2 folders has been fixed.
- # Fixed the copyright icon.
- # Fixed the orientation unit in Complete (Euler) mode.
- # Don't keep the last selection of measurement mode issues has been fixed.
- # Fixed the issue that red badge always display in Advanced button.
- # Fixed the incorrect status bytes in 3 measurement mode.
- # Cannot reconnect reboot sensors automatically after OTA has been fixed.
- # Fixed several crashes.

Version 2020.1.1

Release date: May 19, 2020

Release type: Beta

Compatible firmware versions: 1.0.0, 1.3.0

Cannot do device firmware upgrade or downgrade issue has been fixed