

# Xsens MTi-680G

- > Rugged, IP68 rated RTK GNSS/INS
- > 0.2 deg roll/pitch & cm-level position accuracy
- > Internal u-blox ZED F9 RTK enabled GNSS receiver

receiver



## Description

The MTi-680G is an RTK enabled GNSS/INS with a ruggedized housing featuring IP68 protection against environmental influences. Building on the proven Xsens MTi 600-series technology it enables a robust and easy to use cm-level positioning and orientation tracking for outdoor applications. It features an incredibly powerful onboard u-blox ZED F9 RTK GNSS receiver to provide superior positioning performance. It is designed for easy integration and seamless interfacing with other equipment.

The MTi-680G is supported by the MT Software Suite which includes MT Manager (GUI for Windows/Linux), SDK, example codes and drivers for many platforms including ROS.

- > White label and OEM integration options available
- > 3D models available on request

### Sensor fusion performance

Roll/Pitch	0.2 deg RMS
Yaw/Heading	0.5 deg RMS
Position	1cm+1ppm CEP1
Velocity	0.05m/s RMS

### Gyroscope

Standard full range	2000 deg/s
In-run bias stability	8 deg/h
Bandwidth (-3dB)	520 Hz
Noise Density	0.007 °/s/√Hz
g-sensitivity (calibr.)	0.1 °/s/gz

### Accelerometer

Standard full range	10 g
In-run bias stability	10 (x,y) 15(z) °/g
Bandwidth (-3dB)	500 Hz
Noise Density	60 °/g/√Hz

### Magnetometer

Standard full range	+/- 8 G
Total RMS noise	1 mG
Non-linearity	0.2%
Resolution	0.25 mG

### RTK GNSS receiver

Brand	u-blox
Model	ZED F9
RTK correction input	RTCM 3.2/3.3
RTCM input port	RS232 (38K4-921K6 bit/s)

### Barometer

Standard full range	300-1250 hPa
Total RMS noise	1.2 Pa
Relative accuracy	+/- 8 Pa (~0.5m)

### Mechanical

IP-rating	IP68
Operating Temperature	-40 to 85 °C
Casing material	Aluminum
Mounting orientation	No restriction, full 360° in all axes
Dimensions	56.50x40.90x36.75 mm
Connector	Main: ODU (AMC HD 12 pins) RTCM: ODU (AMC HD 4 pins) Antenna: SMA
Weight	98 g
Certifications	CE, FCC, RoHS

### Electrical

Input voltage	4.5 to 24V
Power consumption (typ)	<1 W

### Interfaces / IO

Interfaces	CAN, RS232
Sync Options	SyncIn, SyncOut, ClockSync
Protocols	Xbus, ASCII (NMEA) or CAN
Clock drift	1ppm
Output Frequency	Up to 2 kHz, 400 Hz SDI
Built-in-self test	Gyro, Acc, Mag, Baro, GNSS

### Software Suite

GUI (Windows/Linux)	MT Manager, Firmware updaters, Magnetic Field Mapper
SDK (Example code)	C++, C#, Python, Matlab, Nucleo, public source code
Drivers	LabVIEW, ROS, GO
Support	Online manuals, community and knowledge base

Unless stated otherwise, all specifications are typical. Specifications subject to change without notice. This document is informational and not binding. Complete and detailed specifications are available at [mtdocs.movella.com](http://mtdocs.movella.com)